

General Operation:

- 1. Press On / Off button to turn on.*
- 2. Press °F/°C button to select temperature scale.*
- 3. Insert stainless steel probe at least 1" into food being tested.*
- 4. Leave probe in food until display stabilizes.*
- 5. Press HOLD button to lock temperature reading.*
- 6. Remove probe from food and press HOLD button again to release reading.*
- 7. Clean by hand. **Do Not** completely immerse thermometer in water or place in dishwasher.*

Battery Replacment:

- 1. Remove silicone backing.*
- 2. Remove screw from casing.*
- 3. Pull case apart.*
- 4. Remove old battery from compartment.*
- 5. Put in new battery with '+' sign showing.*
- 6. Replace screw and silicone.*