

INSTRUCTIONS

This hygrometer/thermometer is designed for indoor use. Relative humidity readings as given in the official weather reports are always outdoor readings. The two should not be confused.

Place your hygrometer/thermometer where it will not be affected by direct sunlight or other heat sources. Reasonable air circulation is advised for best results.

Authorities seem to agree that from 40 to 50% relative humidity, with a temperature of 68° to 70°F, is most desirable.

This hygrometer gives you the current reading. To correct an undesirable relative humidity, humidifying or dehumidifying equipment is required.