

Taylor thermometers and timers are the secret to cooking great meals. You can spend a lot on cookware and appliances, but a simple Taylor thermometer or timer brings it all together for great results. Since 1851 Taylor has provided you with accurate and easy to use instruments. When it comes to food safety and accuracy in measurement, it's no wonder that Taylor is the tool that chefs trust.

Instructions:

1. Press "EVENT" to select a timing event. A "TIME" icon shows in the active timer screen.
2. Press "HR" to set hours. Press "MIN" to set minutes. Hold down the buttons to advance digits quickly.
3. Press "START/STOP" to start the active timer. To pause or restart timing, press "START/STOP". To stop timer and reset to zero, first pause the timer, then press "HR" and "MIN" at the same time.
To "START or PAUSE" a timer, you must be in the event (indicated by the "TIME" icon).
4. Press "EVENT" to select another timer. Repeat the steps to set other timing events.
5. When a time is up, an alarm sounds and the timer counts up. Press "START/STOP" to turn off the alarm and stop the count up. Press "START/STOP" again to recall the last set time. Press "HR" and "MIN" at the same time to reset to zero.
6. Each timer will time up to 24 hours and 59 minutes.

Tips:

- When multiple timers are in use, press "EVENT" to switch between timers.
- Each timer will also count up. Press "EVENT" to select a timer and then press "START/STOP".
- Press "HR", "MIN" and "EVENT" at the same to reset all timers to zero.
- If a time is under 1 hour, the timer switches from Hour/Minute to Minute/Second timing.
("H" icon = hours, "M" icon = minutes, "S" icon = seconds.)
- **Use a dry erase marker only on this unit. Do not use any permanent ink.**

Note: There is a static cling label over the digital display and a strip under the battery cover to prevent battery drain during shipping. Please remove both before use.